## GLUE RECOMMENDATIONS FOR HIGHLINE CUSTOM



## NOTICE

Surfaces must be cleaned from grease and dirt to attain the best result.

## The following products have been tested and approved:

Manufacturer	Product
Bostik	Maxibond     Maxibond X-TREME     Clearbond
Danalim	Montage Ekstra 292     Turbo tack 291
Henkel	Pattex no more nails
Novatech	• Tec7 • Trans7

The products are listed randomly.

All products are construction adhesives.

## Tests performed:

Test	Duration
Soap water	6 days
Cold water / boiling water	Alternately 10 times, three minutes each
Dishwasher	3 runs
Chlorine bath	ı day
Liquid drain cleaner	ı day
Detergent	ı day
Freezer	ı day

